

Built to Last[®]



Adirondack Porch Swing Assembly Instructions



Step 1: Attach front legs. **Important: When advancing the screws keep the drill bit lined up with the screw and apply enough pressure to avoid stripping the head.** Advance the screws until they stick out slightly on the other side to help matching to the hole in the leg. Tighten until snug.



Step 2: Attach the rear legs. Advance the screw slowly so you can feel it go into the existing hole in the frame. **Again, remember to keep the bit lined up and apply pressure to avoid stripping the screw.** Insert the 4 lag eye bolts (with quicklinks attached) and screw them into the existing holes on the 4 legs using a screwdriver.



Step 3:: Set the back section in place as shown. Tilt forward first to clear the curved seat slat, then tilt back into place. Use the 2 shorter screws for the bottom slat. Line up the upper back as shown and advance the screws into the existing holes.



Step 4:: Attach the arms. Advance the screws far enough so you can line up the pieces with the existing holes. Tighten until just snug.

Step 5:: You are ready to hang the swing. We recommend using 3/16" galvanized chain. For an 8' ceiling you will need two 13'6" lengths of chain, a 9' ceiling will use two 15'6" lengths

Install the ceiling bolts: They should be located at least 32" from the wall and slightly further away from each other than the swing is wide, but further apart or slightly less than the width will work fine. Locate the center of the joist/rafter and drill a 5/16" hole and screw in the lag eyebolt. Hang the "S" hook from the bolt.

Attach the chain, hang and adjust for your deired height and slant. Note in the photo above how the chain goes from the front quicklink to the celing then down through the arm lagbolt and then down to the rear quicklink. Excess chain can be draped at the rear quicklink.

Keeping your furniture clean: Maintenance requirements will vary by location. Generally, an occasional rinsing by hose will keep the furniture clean. A pressure washer will do the best job but be careful not to apply too much pressure (which will "feather" the surface). For tough dirt/stains spray Clorox Cleanup or Tilex onto the furniture, allow to sit for a few minutes and rinse off with a hose or pressure wash. Stubborn stains may require a little scrubbing with a scrub-brush.

Enjoy your Adirondack Porch Swing!!!
877-258-2578 - www.built-to-last.com